

CONTENTS

SPECIFICATIONS	1
PANEL LAYOUT	2
Musical Game Functions & Operations(HS-500)	4
LSI Data Table	20
Main WaveForms	24
Disassembly Procedures	27
HS-200 HM1 Circuit Board	32
HS-500 HM2 Circuit Board	34
HS-200 Parts List	
HS-500 Parts List	

SPECIFICATIONS

HS-200

KEY BOARD25 keys (F₂~F₄), 4 notes polyphonic**INSTRUMENT VOICES**

ORGAN	VIOLIN
CLARINET	PIANO
HARPSICHARD	

EFFECT

SUSTAIN
VIBRATO (STRING only)

OTHER CONTROL

Power switch/VOLUME

AUXILIARY JACKS

Headphones
DC input

MAIN AMPLIFIER

500 mW (RMS)

SPEAKER

5.7cm (2-1/4"), 8Ω

POWER SYSTEM

Batteries (five 1.5V SUM-3, "AA" size,
R-6 or equivalent)
Household current/car battery
(with optional adaptors)

POWER CONSUMPTION

850 mW

CABINET COLOR

Ivory white

DIMENTIONS

Width : 31.5 cm (12-3/8")
Depth : 9.5 cm (3-3/4")
Heigh : 3.0 cm (1-1/8")

WEIGHT (excluding batteries)

400 g (14 oz)

ACCESSORY INCLUDED

Protective soft case

Semi-conductor

LSI	: 1
IC	: 3
Transistor	: 3
FET	: 1
Diode	: 33

HS-500

KEYBOARD25 keys (F₂~F₄), 4 notes polyphonic**INSTRUMENT VOICES**

ORGAN	VIOLIN
CLARINET	PIANO
HARPSICHORD	

EFFECT

SUSTAIN
VIBRATO (STRING only)

MUSICAL GAMES

5 types with three levels of difficulty for each game

DISPLAY (liquid crystal type)

Function/Level/Score/Answer/♪♪♪ (note name)

OTHER CONTROL

Power switch/VOLUME

AUXILIARY JACKS

Headphones
DC input

MAIN AMPLIFIER

500 mW (RMS)

SPEAKER

5.7 cm (2-1/4"), 8Ω

POWER SYSTEM

Batteries (five 1.5V SUM-3, "AA" size,
R-6 or equivalent)
Household current/car battery (with optional adaptors)

POWER CONSUMPTION

850 mW

CABINET COLOR

Ivory white

DIMENTIONS

Width: 31.5 cm (12-3/8")
Depth: 9.5 cm (3-3/4")
Heigh: 3.0 cm (1-1/8")

WEIGHT (excluding batteries)

450 g (1 lb.)

ACCESSORY INCLUDED

Protective soft case

Semi-conductor

LSI	: 2
IC	: 3
Transistor	: 3
FET	: 1
Diode	: 35
Display	: 1

(HS-500)

Part Name	μ PD7503G	Function Name	μ -Computer for Musical Game
-----------	---------------	---------------	----------------------------------

Pin		Description	Pin		Description
No.	Nama		No.	Nama	
1	NC	NO connection	64	P33	Port 3 (4 bit) OUT
2	P32	} Port 3 (4 bit) OUT	63	P10/INT.0	} Used as in terraption Signal IN
3	P31		62	P11	
4	P30		61	P12	} Port 1 (4 bit) IN
5	P30/SI		60	P13	
6	P02/SO	} Port 0 (3 bit) (Used both as Serial data IN) (Used both as Serial data OUT) (Used as Serial Clock Pulse OUT)	59	CL2	R.C Connection for System Clock OSC
7	P01/SCK		58	Vss	DC Supply IN(+7.5V)
8	P63		57	CL1	R.C Connection for System Clock OSC
9	P62	} Port 6 (4 bit) IN/OUT(Programable)	56	RESET	Initial Clear IN
10	P61		55	INT.1	Interruption Signal IN
11	P60		54	S0	} Segment Signal OUT for LCD drive
12	P53		53	S1	
13	P52	52	S2		
14	P51	51	S3		
15	P50	50	S4		
16	P43	49	S5		
17	P42	48	S6		
18	P41	47	S7		
19	P40	46	S8		
20	X2	45	S9		
21	X1	44	S10		
22	V _{DD}	43	S11		
23	VCL3	42	S12		
24	VCL2	41	S13		
25	VCL1	40	S14		
26	V _{SS}	39	T15		
27	COM3	38	S16		
28	COM2	37	S17		
29	COM1	36	S18		
30	COM0	35	T19		
31	S23	34	S20		
32	S22	33	S21		

Microcomputer Operation Outline


• Microcomputer operation outline

μ PD7503G performs transfer between the commands and key codes shown in the table below and the music source IC (GH-2).


The sequence and timing are as shown in the timing chart and the switching timing is in accordance with the selected function, START button, keying timing, etc.

Command	Command Code	Function
NORMAL	000	GH-2 (music source IC) independently produces notes in accordance with the keying without receiving a key code from the microcomputer.
μ -COM	010	GH-2 produces notes in accordance with the key code from the microcomputer and the keyed data is ignored.
READ	001	GH-2 directs the keyed data (key code) to the microcomputer.
WRITE	011	GH-2 receives the data from the microcomputer and produces notes accordingly.

• μ PD7503G Data Timing Chart



• Terminal connection view (Top View)



MAIN WAVEFORMS


1 Master Clock Pulse (ϕ)

●CHECK POINT

IC1 (GH-1) 9th Pin . . . HS-200
 IC2 (GH-2) 24th Pin . . . HS-500

●CONDITION

Power Switch – ON




2 Initial Clear (IC)

●CHECK POINT

IC1 (GH-1) 12th Pin . . . HS-200
 IC2 (GH-2) 21st Pin . . . HS-500

●CONDITION

Power Switch – ON/OFF




3-1 Sound Source "ORGAN"

●CHECK POINT

IC1 (GH-1) 11th Pin . . . HS-200
 IC2 (GH-2) 20th Pin . . . HS-500

●CONDITION

1. Set Tone Selector SW. to "ORGAN".
2. Depress C₃ Key




3-2 Sound Source "STRING"

●CHECK POINT

IC1 (GH-1) 11th Pin . . . HS-200
 IC2 (GH-2) 20th Pin . . . HS-500

●CONDITION

1. Set Tone Selector SW. to "STRING".
2. Depress C₃ Key




**3-3 Sound Source
"CLARINET"**

●CHECK POINT

IC1 (GH-1) 11th Pin . . . HS-200
IC2 (GH-2) 20th Pin . . . HS-500

●CONDITION

1. Set Tone Selector SW. to "CLARINET".
2. Depress C₃ Key




**3-4 Sound Source
"PIANO"**

●CHECK POINT

IC1 (GH-1) 11th Pin . . . HS-200
IC2 (GH-2) 20th Pin . . . HS-500

●CONDITION

1. Set Tone Selector SW to "PIANO".
2. Depress C₃ Key




**3-5 Sound Source
"HARPSICHORD"**

●CHECK POINT

IC1 (GH-1) 11th Pin . . . HS-200
IC2 (GH-2) 20th Pin . . . HS-500

●CONDITION

1. Set Tone Selector SW. to "HARPSICHORD".
2. Depress C₃ Key




**4-1 Tone Signal
"ORGAN"**

●CHECK POINT

Tr3 Emitter HS-200, HS-500

●CONDITION


1. Set Tone Selector SW. to "ORGAN".
2. Depress C₃ Key



4-2 Tone Signal "STRING"

●CHECK POINT
Tr3 Emitter HS-200, HS-500


- CONDITION
1. Set Tone Selector SW. to "STRING".
 2. Depress C₃ Key



4-3 Tone Signal "CLARINET"

●CHECK POINT
Tr3 Emitter HS-200, HS-500


- CONDITION
1. Set Tone Selector SW. to "CLARINET".
 2. Depress C₃ Key



4-4 Tone Signal "PIANO"

●CHECK POINT
Tr3 Emitter HS-200, HS-500


- CONDITION
1. Set Tone Selector SW. to "PIANO".
 2. Depress C₃ Key



4-5 Tone Signal "HARPSICHORD"

●CHECK POINT
Tr3 Emitter HS-200, HS-500

- CONDITION
1. Set Tone Selector SW. to "HARPSICHORD".
 2. Depress C₃ Key



Disassembly Procedures **HS-200** **HS-500**

- 分解は、やわらかい布などを敷いた上で、製品に傷をつけないように十分注意して作業を行なってください。

- Before disassembly, lay a soft cloth on the flat surface so that the product is not scratched or marked while it is being disassembled.

1. 下ケースの取り外し方

- ① ユニットの裏がえし、電池カバーを外し、電池5本を取り出します。
- ② 図1の矢印(A)~(F)の穴の中の止めネジ(6本)を⊕ドライバーで取り外します。

1. Removal of Lower case

- (1) Turn over the unit, remove the battery cover and take out the 5 batteries.
- (2) Remove the six screws in holes (A) – (F) indicated by the arrows in Fig. 1.




図1 Fig. 1

- ③ ユニットの図2に示すように、電池カバーが上側になるように起し、下ケースの矢印(G)の部分を押すと内側の爪がはずれますので、左右にゆっくり開いてください。
図3の状態電源コードをシートから取り外し、上ケースと下ケースを分離します。

- (3) Set the unit upright as in Fig. 2 so that the battery cover is on the top. The inside tabs can be disengaged when the arrow (G) is pressed. Allow the unit to open slowly on both sides.




図2 Fig. 2




図3 Fig. 3

2. HM1シートの取り外し方(HS-200)

スピーカのコネクタをシートから取り外します。

図4の矢印(A)~(F)の止めネジ(6本)を⊕ドライバーで取り外します。

注) HM1シートのスイッチ接点部には「導電グリス」が塗ってありますので、手等で触らないよう注意してください。

2. Removal of HM1 circuit board (HS-200)

Remove the speaker connector from the circuit board. Remove the six screws in holes (A) – (F) indicated by the arrows in Fig. 4.

Note: Take care not to touch the “conductive grease” which has been applied to the switch contact section on the HM1 circuit board.




図4 Fig. 4

2. HM2シートの取り外し方(HS-500)

スピーカのコネクタをシートから取り外します。

図5の矢印(A)~(H)の止めネジ(8本)を⊕ドライバーで取り外します。

注) HM2シートのスイッチ接点部には「導電グリス」が塗ってありますので、手で触らないよう注意してください。

2. Removal of HM2 circuit board (HS-500)

Remove the speaker connector from the circuit board. Remove the eight screws in holes (A) – (H) indicated by the arrows in Fig. 5.

Note: Take care not to touch the “conductive grease” which has been applied to the switch contact section on the HM2 circuit board.




図5 Fig. 5

3. 鍵盤の取り外し方(HS-200)

図6の矢印の止めネジ(3本)を⊕ドライバーで取り外します。(HS-200)

3. Removal of keyboard (HS-200)

Remove the three screws indicated by the arrows in Fig. 6.




図6 Fig. 6

3. 鍵盤の取り外し方(HS-500)

図7の矢印の止めネジ(2本)を⊕ドライバーで取り外します。(HS-500)

3. Removal of keyboard (HS-500)

Remove the two screws indicated by the arrows in Fig. 7.




図7 Fig. 7

白鍵は、両手を添えてゆっくり持ち上げ取り外してください。(図8参照)

黒鍵は、矢印方向に少し押し出してから、両手を添えてゆっくり持ち上げ取り外してください。(図9参照)

注) 白鍵及び黒鍵は一体化されていますので、取り扱いには注意してください。

Lift the white keys using both hands slowly to remove. (Refer to Fig. 8)

To remove the black keys, push out slightly in the direction of the arrow and then lift using both hands. (Refer to Fig. 9)

Note: The white keys and black keys are consisted as a single entity and care is required in handling them.




図8 Fig. 8




図9 Fig. 9

※取り付ける場合は、黒鍵をシートの切り込み穴に確実にはめ込んでから白鍵を取り付け、ネジで止めてください。

* For re-assembly, fit the black keys into the holes in the circuit board, then mount the white keys and secure with the screws.

4. スイッチ接点ゴムの取り外し方

- ①スイッチ接点ゴムの足をピンセットで押し込みます。(図10)
- ②スイッチ接点ゴムを指でつまみ上げ、ゆっくり取り外します(図11)。外れにくい場合は、接点ゴムの足をピンセットではさみ引き抜いて外してください。




図10 Fig. 10

4. Removal of switch contact rubber

- (1) Push in the foot of the switch contact rubber using a pair of tweezers.
- (2) Take the switch contact rubber between your fingers and remove it slowly. If it is hard to remove, use the tweezers to grasp the projections of contact rubber and pull them out to remove.




図11 Fig. 11

※接点ゴムの足をシートの穴に差し込み、部品側からピンセットでつまみ、ゆっくり引いてください。

* Re-assembling the switch contact rubber
Insert the productions of contact rubber into the hole provided in the circuit board, grasp it from the parts side using the tweezers and pull it slowly.

5. スイッチつまみ、スライダーユニットの取り外し方

スイッチつまみを引き抜くと、スライダーユニットは、上ケースの裏側から取り外すことができます。

5. Removing the switch knob and slider unit

When the switch knob is pulled out, the slide unit can be taken out from the rear side of the upper case.




図12 Fig. 12

6. 液晶表示器(LCD)の取り外し方(HS-500)

- ①ラジオペンチで、液晶表示器を止めているツメ3本を起こします。(図13参照)
- ②液晶表示器を指ではさみ、ゆっくり起こし、図14のようにシートから外します。




図13 Fig. 13

※取り付ける場合は、インターコネクタの接点部をやわらかい布等で軽く拭いてから取り付けてください。

6. Removing the liquid crystal display (LCD) (HS-500)

- (1) Pull up the three tabs which engage the liquid crystal display using pliers. (Refer to Fig. 13)
- (2) Grasp the liquid crystal display between fingers, pull it up slowly and remove it from the circuit board as shown in Fig. 14.




図14 Fig. 14

* For re-assembly, wipe the contacts of the inter-connector carefully with a soft cloth first and then proceed to re-assemble.

YAMAHA

HandySound

HS-200

PARTS LIST


A. Electronic Components(電気部品)	2
B. Lower Case Assembly(下ケース)	3
C. Upper Case Assembly & keyboard Assembly(上ケース, 鍵盤)	4

A. Electronic Components (電気部品)

Ref. No.	Part No.	Description	部 品 名	Remarks	Common Model	Markets
*	NB 10:50:80	HM1 Circuit Board Assembly		H M 1 シ ー ト Ass'y		
*	iG 06:05:00	IC Regulator	78L008P	I C 三 端 子 レ ギ ュ レ ー タ	Power Regulator	HS-500
*	iG 06:06:00	- do. -	LA4142	//	Power Amp.	HS-500
*	iG 06:44:00	- do. -	iG06440	//	Auto Power OFF	HS-500
*	iT 10:08:00	- do. -	YM1008	//	GH-1	
	iA 07:33:40	Transistor	2SA733(P)(Q)	ト ラ ン ジ ス タ		
	iC 18:15:70	- do. -	2SC1815(O)(Y)	//		
	iE 10:26:00	FET	2SK246(Y)	F E T		
*	iF 00:13:80	Diode	1SS84	ダ イ オ ー ド		
*		- do. -	1SS133	//	Servicing 1S1555	
*	iF 00:04:60	- do. -	1S1555	//		
*	FS 54:51:00	Semi-Conductive Ceramic Capacitor	0.1 BC-12V	半 導 体 セ ラ ミ ッ ク コ ン デ ン サ		
*	FS 78:31:00	- do. -	1000pF BC-111 25V	//		
*	FS 78:31:50	- do. -	1500pF	//		
*	FS 78:32:20	- do. -	2200pF	//		
*	FS 78:41:00	- do. -	0.01	//		
*	FS 78:41:50	- do. -	0.015	//		
*	FS 78:46:80	- do. -	0.068	//		
*	QU 00:19:00	Ceramic Vibrator	343.4kHz	セ ラ ミ ッ ク 振 動 子		HS-500
*	LB 10:08:50	Jack (External DC-IN)		D C - I N ジャ ッ ク		HS-500
*	LB 10:08:60	Jack (Headphones)		H ・ P ジャ ッ ク		HS-500
*	LB 20:14:10	Connector, Side Type 2P		2 P コ ネ ク タ		HS-500
*	LB 20:21:70	Bass Post, Top Type 2P		ベ ー ス 付 ポ ス ト 2 P		HS-500
*	LA 00:37:80	RT Pin		R T ピ ン		HS-500
*	BB 00:54:60	Contact Leaf, Battery		電 池 端 子 (+)		HS-500
*	AA 05:43:10	Contact Spring(Spiral), Battery		// (-)		HS-500

* New Parts (新規部品)

C. Upper Case Assembly & Keyboard Assembly (上ケース, 鍵盤)



Ref. No.	Part No.	Description	部 品 名	Remarks	Common Model	Markets
※ 1	CA 01 36 50	Soft Case	ソ フ ト ケ ー ス		HS-200	
※ 2	NK 00 76 50	Upper Case	上 ケ ー ス			
※ 3	NB 10 57 70	HM2 Circuit Board Assembly	H M 2 シ ー ト Ass'y			
※ 4	Ei 32 60 80	Pan Head Tapping Screw	ナベタッピングネジ	2.6 x 8		
※ 5	CB 04 12 10	Knob, Slide Switch	スライドSW. ツマミ	INSTRUMENT SUSTAIN ON/OFF POWER/VOLUME	HS-200	
※ 6	CB 04 19 10	Dust Protection Film, Slide Switch	防 塵 フ ィ ル ム	POWER/ VOLUME	HS-200	
※ 7	CB 04 19 20	- do. -	//	INSTRUMENT	HS-200	
※ 8	KA 40 10 00	Slider Unit, Slide Switch	スライダユニット		HS-200	
※ 9	KA 40 10 10	- do. -	//		HS-200	
※ 10	CB 04 12 20	Push Button	プッシュSWボタン	FUNCTION LEVEL START		
※ 11	CB 04 11 80	White Key Assembly	白 鍵 Ass'y		HS-200	
※ 12	CA 01 37 70	Cushion II	ク ッ シ ョ ン II		HS-200	
※ 13	CB 04 11 90	Black Key Assembly	黒 鍵 Ass'y		HS-200	
※ 14	CE 02 04 20	Screen, Speaker	ク レ モ ナ		HS-200	
※ 15	JA 06 51 00	Loud Speaker	ス ピ ー カ		HS-200	
※ 16	AA 05 41 00	Fixture, Loud Speaker	S P 取 付 け 用 金 具		HS-200	
※ 17	CB 04 12 50	Rubber Contact	ゴ ム 接 点		HS-200	
※ 18	CB 04 12 60	- do. - , Push Switch	プッシュSW接点ゴム			
※ 19	AA 05 38 50	Frame, LCD Display	液 晶 フ レ ー ム			
※ 20	JN 10 00 10	LCD Display	液 晶 パ ネ ル			
※ 21	CB 04 22 90	Inter-Connector, LCD Display	イ ン タ ー コ ネ ク タ			
※ 22	CB 04 22 80	Dummy Connector, LCD Display	ダ ミ ー コ ネ ク タ			
※ 23	CA 01 37 80	Blind Cover Sheet, Circuit Board	シ ー ト カ バ ー			
※ 24	CB 04 25 30	Panel Template, Japanese Description	和 文 シ ー ト	for Only Japanese Model		

※ New Parts (新規部品)



YAMAHA

HandySound

HS-500

PARTS LIST


A. Electronic Components(電気部品)	2
B. Lower Case Assembly(下ケース)	3
C. Upper Case Assembly & keyboard Assembly(上ケース, 鍵盤).....	4

A. Electronic Components (電気部品)

Ref. No.	Part No.	Description	部 品 名	Remarks	Common Model	Markets
	NB 10:57:70	HM2 Circuit Board Assembly	H M 2 シ ー ト Ass'y			
*	iG 06:05:00	IC Regulator	78L008P	I C 三 端 子 レ ギ ュ レ ー タ	Power Regulator	HS-200
*	iG 06:06:00	-- do. --	LA4142	"	Power Amp.	HS-200
*	iG 06:07:00	-- do. --	μPD7503G	"		
*	iG 06:44:00	-- do. --	iG06440	"	Auto Power OFF	HS-200
*	iT 10:18:00	-- do. --	YM1018	"		GH-2
	iA 07:33:40	Transistor	2SA733(P)(Q)	ト ラ ン ジ ス ト		
	iC 18:15:70	-- do. --	2SC1815(O)(Y)	"		
	iE 10:26:00	FET	2SK246(Y)	F E T		
	iF 00:13:80	Diode	1SS84	ダ イ オ ー ド		
		-- do. --	1SS133	"	Servicing 1S1555	
	iF 00:04:60	-- do. --	1S1555	"		
	iF 00:26:70	Zener Diode	0.5Z5.1Y	ツ ェ ナ ー ダ イ オ ー ド		
*	JN 10:00:10	LCD Display		液 晶 パ ネ ル		
*	CB 04:22:90	Inter-Connector, LCD Display		イ ン タ ー コ ネ ク タ		
*	FS 54:51:00	Semi-Conductive Ceramic Capacitor	0.1 DC-12V	半 導 体 セ ラ ミ ッ ク コ ン デ ン サ		
*	FS 78:31:00	-- do. --	1000 DC-25V	"		
*	FS 78:32:20	-- do. --	2200	"		
*	FS 78:41:00	-- do. --	0.01	"		
*	FS 78:41:50	-- do. --	0.015	"		
*	FS 78:46:80	-- do. --	0.068	"		
*	QU 00:19:00	Ceramic Vibrator	343.4kHz	セ ラ ミ ッ ク 振 動 子		HS-200
*	QU 00:21:00	Quartz Vibrator	32.768kHz	水 晶 振 動 子		
*	LB 10:08:50	Jack (External DC-IN)		D C - I N ジャ ッ ク		HS-200
*	LB 10:08:60	Jack (Headphones)		H ・ P ジャ ッ ク		HS-200
*	LB 20:14:10	Connector, Side Type 2P		2 P コ ネ ク タ		HS-200
*	LB 20:21:70	Bass Post, Top Type 2P		ベ ー ス 付 ポ ス ト 2 P		HS-200
*	LA 00:37:80	RT Pin		R T ピ ン		HS-200
*	BB 00:54:60	Contact Leaf, Battery		電 池 端 子 (+)		HS-200
*	AA 05:43:10	Contact Spring(Spiral), Battery		" (-)		HS-200

* New Parts (新規部品)

C. Upper Case Assembly & Keyboard Assembly (上ケース, 鍵盤)




Ref. No.	Part No.	Description	部 品 名	Remarks	Common Model	Markets
* 1	CA 01 36 50	Soft Case	ソ フ ト ケ ー ス		HS-500	
* 2	NK 00 76 30	Upper Case	上 ケ ー ス			
* 3	NB 10 50 80	HM1 Circuit Board Assembly	H M 1 シ ー ト Ass'y			
4	Ei 32 60 80	Pan Head Tapping Screw	2.6 x 8 ナベタッピングネジ	BLACK		
* 5	CB 04 12 10	Knob, Slide Switch	スライドSW. ツマミ	POWER/VOLUME SUSTAIN ON/OFF INSTRUMENT	HS-500	
* 6	CB 04 19 10	Dust Protection Film, Slide Switch	防 塵 フ ィ ル ム	VOLUME	HS-500	
* 7	CB 04 19 20	- do. -	//	INSTRUMENT	HS-500	
* 8	KA 40 10 00	Slider Unit, Slide Switch	2T スライダユニット		HS-500	
* 9	KA 40 10 10	- do. -	1T //		HS-500	
* 10	CB 04 11 80	White Key Assembly	白 鍵 Ass'y		HS-500	
* 11	CA 01 37 70	Cushion II	ク ッ シ ョ ン II		HS-500	
* 12	CB 04 11 90	Black Key Assembly	黒 鍵 Ass'y		HS-500	
* 13	CE 02 04 20	Screen, Speaker	ク レ モ ナ		HS-500	
* 14	JA 06 51 00	Loud Speaker	ス ピ ー カ		HS-500	
* 15	AA 05 41 00	Fixture, Loud Speaker	S P 取 付 け 金 具		HS-500	
* 16	CB 04 12 50	Rubber Contact	ゴ ム 接 点		HS-500	
* 17	CA 01 36 60	Blind Cover Sheet, Circuit Board	シ ー ト カ バ ー			
* 18	CB 04 25 20	Panel Template, Japanese Description	和 文 シ ー ト	for Only Japanese Model		

* New Parts (新規部品)




PANEL LAYOUT


HS-200



HS-500



1. OPERATING PROCEDURE



KINDS OF GAMES (FUNCTION)


- Function 1: Keyed note name display (not a game)
- Function 2: Note name guessing game
- Function 3: Note guessing game
- Function 4: Phrase guessing game
- Function 5: Chord guessing game
- Function 6: Tennis game

LEVELS

3 levels from 1 to 3.

2. MICROCOMPUTER AND LCD DISPLAY TEST

If the is turned ON while simultaneously pressing the "FUNCTION" and "START" switches, the microcomputer and LCD display will go into a test mode.




Musical Game Functions & Operations(HS-500)

3. MANIPULATION AND OPERATION


The manipulation and operation for each function are shown below.

• How to read the chart




The microcomputer processes based on the input operation and response output can be obtained.


- Function N Chart title
- Indicates that there is an input operation.
- Shows the display contents prior to the input operation.
- Displays the results that were processed by the microcomputer using the input operation.
- Indicates a judgement.
- A → B Indicates B occurs as a result of A.
- A → B Indicates movement passes from A to B.
- A - - - - -> B Indicates B is processed based on A.



KEYED NOTE
NAME DISPLAY
(FUNCTION 1)




NOTE NAME GUESSING (FUNCTION 2)




*Refer to the Basic Operation Chart


NOTE GUESSING (FUNCTION 3)




* Refer to the Basic Operation Chart



**CHORD
GUESSING
(FUNCTION 5)**



* Refer to the Basic Operation Chart




Note) The ball means a note gliding on the keyboard.

(HS-200)

Part Name	YM1008	Function Name	GH-1(Generator, Handy Sound-1)
-----------	---------------	---------------	---------------------------------------

Pin No.		Name	Description	Pin No.		Name	Description
1	N2	Note terminal,	C [#] ,G	16	N3	Note terminal,	D, G [#]
2	N7	Note terminal,	C, F [#]	15	N4	Note terminal,	D [#] ,A
3	N6	Note terminal,	B, F	14	N5	Note terminal,	E, A [#]
4	B22	Block terminal,	B ₃ ~E ₄	13	FU	※Function terminal	
5	B21	Block terminal,	F ₃ ~A ₃ [#]	12	IC	Initial Clear Signal IN	
6	B12	Block terminal,	B ₂ ~E ₃	11	AO	Sound Source Signal OUT	
7	B11	Block terminal,	F ₂ ~A ₂ [#]	10	V _{DD}	DC Supply IN	
8	V _{SS}	DC Supply IN (+7.5V)		9	φ	Master Clock Pulse IN(343.35KHz)	




※ Function terminal:for Tone Selection, SUSTAIN and F₄ note terminal

Ⓛ Number:Refer to Waveform photo graphs in this manual.

(HS-200·HS-500)

Part Name	iG06440	Function Name	Auto Power Off Control
-----------	----------------	---------------	-------------------------------

Pin No.		Name	Description
1			Primary DC Supply IN(positive)
2			Secondary DC Supply OUT
3			Power Switch ON/OFF Control IN
4			Start up Capacitor connection terminal
5			Primary DC Supply IN(Negative)
6			Auto Power OFF timing Setting
7			Control Signal Sensitivity Adjustment IN
8			Control Signal IN
9			Power Switch ON/OFF,Timer Reset control





LSI Data Table

(HS-200·HS-500)

Part Name	iG0606 (LA4142)	Function Name	Power Amplifier
-----------	------------------------	---------------	------------------------

Pin No.		Name	Description
1			Capacitor Connection for Priventing oscillation
2			Audio Signal IN
3			Gain Control
4			Capacitor Connection for Priventing oscillation
5			DC Supply IN(V _{CC})
6			Audio Signal OUT
7			DC Supply IN(V _{EE})
8			Bootstrap Capacitor Connection
9			Decoupling Capacitor Connection


· LA 4142 Fquivalent circuit diagram



(HS-500)

Part Name	YM10180	Function Name	GH-2(Generator, Handy Sound-2)
-----------	----------------	---------------	---------------------------------------


Pin No.		Name	Description	Pin No.		Name	Description
1	V _{SS}	Primary DC Supply IN(+7.5V)		24	φ 1	Master Clock Pulse IN (343.35KHz)	
2	CL	μCOM Clock Pulse IN		23	φ 2	No connection	
3	CONT	Control data IN from μCOM		22	V _{DD}	Primary DC Supply IN(Ground)	
4	DI	Data IN from μCOM		21	IC	Initial Clear Signal IN	
5	DO	Data OUT to μCOM		20	AO	Sound Source Signal OUT	
6	NC	NO Connection		19	NC	No connection	
7	B11	Block terminal, F ₂ ~A ₂ [#]		18	NC	No connection	
8	B12	Block terminal, B ₂ ~E ₃		17	FU	※Function terminal	
9	B21	Block terminal, F ₃ ~A ₃ [#]		16	N5	Note terminal, E, A [#]	
10	B22	Block terminal, B ₃ ~E ₄		15	N4	Note terminal, D [#] , A	
11	N6	Note terminal, B, F		14	N3	Note terminal, D, G [#]	
12	N7	Note terminal, C, F [#]		13	N2	Note terminal, C [#] , G	



※Function terminal:for Tone Selection, SUSTAIN and F₄ note terminal

HS-200 HM1 Circuit Board


S/# 4001 ~ 4075



Component Side (部品側)

KEP-NA10803 - 1Y Δ

S/# 11076 ~




Component Side (部品側)

KEP-NA 10803-21

- (Note)
- | | |
|---------------------|-------------------------------|
| 1. LC28752 | : S/# 4001 ~ 4075 |
| LC28754 | : S/# 11076 ~ |
| 2. IC | |
| IC1 | : YM1008 |
| IC2 | : LA4142 |
| IC3 | : IG06440 |
| IC4 | : 78L008P |
| 3. Transistor | |
| Tr1, 3 | : 2SC1815 (O) (Y) |
| Tr2 | : 2SA733 (P) (Q) |
| 4. FET | |
| FET1 | : 2SK246 (Y) |
| 5. Diode | |
| D1 ~ 31 | : 1SS133 (Servicing : 1S1555) |
| D32, 33 | : 1SS84 |
| 6. Ceramic Vibrator | : 343.4 kHz |

HS-500 HM2 Circuit Board



Component Side (部品側)

(Note)

1. LC28761
2. IC
 - IC1 : μ PD7503G
 - IC2 : YM1018
 - IC3 : LA4142
 - IC4 : IG06440
 - IC5 : 78L008P
3. Transistor
 - Tr1.3 : 2SC1815 (O) (Y)
 - Tr2 : 2SA733 (P) (Q)
4. FET
 - FET1 : 2SK246 (Y)
5. Diode
 - D1 ~ 32 : 1SS133 (Servicing : 1S1555)
 - D 33, 34 : 1SS84
6. Ceramic Vibrator : 343.4 kHz
 Quatz Vibrator : 32.768 kHz